

# Head-separated•Dual display For Gas

DPH-100 series DPC-100 series

Ro

RoHS compatible

CE





# Single axis type Free-turning structure\*




Industry first! The hexagonal wrench installation makes a break through in installation method.






# Dual display + Direct setting

<Taking from the operations of the DP-100 series>




Dual display direct setting makes operation much more novel.











Obstructions can be avoided and installation from above can be done much more easily using a hexagonal wrench. This also eliminates wasted installation space and contributes to a smaller installation footprint.




addition, the flat installation leaves no worries for danger of objects striking against the sensor and damaging it.





SUNX



Stainless steel pressure ports come in 3 shapes M3 male thread M5 male thread R/smale thread + M5 female thread Stainless steel is strong and does not bend easily

## Industry fastest\* **Reduced tact time**

#### Suitable for high-speed applications

Industry fastest response time contributes to even greater productivity.

\* Based on research conducted by SUNX as of March 2008.

#### Industry fastest at 500 µs

# Setting is smooth and easy

#### The controller's setting operation mode has a 3-level configuration to suit the frequency of use

The setting levels are clearly separated into "RUN mode" for operation settings that are carried out daily, "MENU SETTING mode" for basic settings, and "PRO mode" for special and detailed setting. These make setting operations easy to understand and easy to carry out.

#### **RUN mode**



Settings such as threshold value adjustment and key lock operation can be carried out while the sensor is operating.

can be carried out.

#### SETTING mode **RUN mode** Simple setting Basic settings such as output mode setting and NO / NC switching can MENU SETTING mode be carried out. RO mode PRO mode High-level function settings such as Special and hysteresis adjustment detailed setting and the copy function

#### 3-color display lets you view the controller status at a glance

The main display color switches between green and red in accordance with the ON / OFF status of output during RUN mode. In addition, the display always appears orange while setting is in progress, so that the status of the controller can be viewed at a glance.

> 10/2008 SUNX




While setting is in progress Menu setting mode PRO mode

Orange while setting is in progress.






# Initial setting work is reduced



#### Copy function reduces man-hours and human error

The controller will automatically recognize sensor heads when they are connected, even for sensor heads with different rated pressure ranges. There is no need to use the controller to change settings.

Sensor head auto-recognition




## **Other useful functions**

# 1 model to suit a wide variety of applications DPC-100 original functions


#### Equipped with independent two output and three output modes


Equipped with two independent comparative outputs, and separate sensing modes can be selected for each of them. Two comparative outputs are provided, so that one of the outputs can be used as a warning output. In addition, if an output is not being used, it can be disabled.

# • Vacuum breakdown can also be checked during suction applications!



 Reference pressure alarm output is possible during reference pressure checking!






Analog voltage output 1 to 5 V
 Analog current output 4 to 20 mA

Notes: 1) Hysteresis can be fixed to one of eight different levels. 2) " P- + " appears in the sub display for comparative output 1, and " P- 2" appears for comparative output 2.

#### 2 Hysteresis mode

1 EASY mode


This mode is used for setting comparative output hysteresis to the desired level and for carrying out ON / OFF control.



Note: "H<sub>1</sub> - +" or "L<sub>0</sub>-+" appears in the sub display for comparative output 1, and "H<sub>1</sub> -2" or "L<sub>0</sub>-2" appears for comparative output 2.

#### 3 Window comparator mode

This mode is used for setting comparative output ON and OFF at pressures within the setting range.




Notes: 1) Hysteresis can be fixed to one of eight different levels.
2) "H<sub>1</sub> - 1" or "L<sub>0</sub> - 1" appears in the sub display for comparative output 1, and "H<sub>1</sub> - 2" or "L<sub>0</sub> - 2" appears for comparative output 2.





#### Equipped with auto-reference / remote zero-adjustment functions, More precise pressure management is possible with a minimum of effort



When auto-reference input is applied, the reference pressure "30" is added to the threshold level. If the reference pressure changes to "20" or "40", the auto-reference input compensates for this every time by changing the threshold level, so any variation in the filling pressure can be ignored.

When remote zero-adjustment input is applied, the reference pressure is forced to "0".

If the reference pressure changes to "20" or "40", the remote zero-adjustment input adjusts the reference pressure to "0" every time the reference pressure changes, so any variation in the filling pressure can be ignored.

# **Other useful functions**

#### Sub display can be customized

The sub display can be set to indicate any other desired values or letters apart from the threshold value. This eliminates the need for tasks such as affixing a label to the device to indicate the normal pressure value.



#### Peak hold and Bottom hold functions


The peak values and bottom values for fluctuating pressures can be displayed using the dual display.



Blinks alternately


#### Response time can be changed

The response time can be changed in 12 levels from 500  $\mu s$  to 5,000 ms. This prevents chattering and incorrect operation due to sudden changes in pressure.



#### Setting details can be understood at a glance

The **DPC-100** setting details appear in the digital display. Because the settings are in numeric form that can be easily understood, it is useful for times such as when receiving technical support by telephone.



#### Energy-saving design! Equipped with an ECO mode

This mode lowers the display luminance to cut power consumption by approximately 30 %. The displays can also be turned off completely to achieve a power saving of approximately 40 %.



#### Display refresh rate can be varied

The display refresh rate for the digital displays can be changed to one of three settings: 250 ms, 500 ms or 1,000 ms. Flickering of the display can be reduced by making the display refresh rate longer.

#### **Emergency reset function**

If there is a problem with the emergency sensor settings, they can be returned to the default settings.






# Installation is also easy!

#### Tight installation to panels is possible

An exclusive mounting bracket (**MS-DP1-2**) that is suitable for 1 to 6 mm 0.039 to 0.236 in panel thickness is available.




# An exclusive mounting bracket (MS-DP1-6) that supports tight installation is available

Space saving can also be obtained if an L-shaped mounting bracket is used.





# Power supply cable can be connected with one-touch connection



\* Options: 5 m 16.404 ft type is also available.

# Types without connector attached cable are also available DPC-10\_-J


Commercially-available connectors can be used for cable connections. Only the required length of cable needs to be used, which contributes to a reduced amount of wastage for unneeded cable.



 \* Refer to p.12 for details on recommended commerciallyavailable connectors.



#### **PRODUCT CONFIGURATION**



#### ORDER GUIDE

#### **Sensor heads**

	Type Appearance Rated p		Appearance         Rated pressure range         Model No.         Pressure port		Pressure port	Applicable fluid
				DPH-101	R <sup>1</sup> /8 male thread + M5 female thread	
	ipound sure	DPH-10□-M3(-R)		DPH-101-M3	M3 male thread	
		OW	100.0 to 1100.0 kDo	DPH-101-M5	M5 male thread	
			–100.0 to +100.0 kPa	DPH-101-R	R <sup>1</sup> / <sub>8</sub> male thread + M5 female thread	-
	Flexible cable type	DPH-10□-M5(-R)		DPH-101-M3-R	M3 male thread	
				DPH-101-M5-R	M5 male thread	]
Deei	tivo processo	O M	0 to +1.000 MPa	DPH-102	R <sup>1</sup> / <sub>8</sub> male thread + M5 female thread	Air,
POSI	tive pressure		0 to +1.000 MPa	DPH-102-M5	M5 male thread	non-corrosive gas
		cible 0 to -101.0 k			R <sup>1</sup> / <sub>8</sub> male thread + M5 female thread	-
Vacu	um pressure		1	DPH-103-M3	M3 male thread	-
			0 to 101.0 kDo	DPH-103-M5	M5 male thread	
	Flexible cable type		0 to -101.0 kPa	DPH-103-R	R <sup>1</sup> /8 male thread + M5 female thread	
				DPH-103-M3-R	M3 male thread	
				DPH-103-M5-R	M5 male thread	

#### 5 m 16.404 ft cable length type

5 m 16.404 ft cable length type (standard: 2 m 6.562 ft) is also available. When ordering this type, suffix"-C5" to the Model No. (e.g.) 5 m 16.404 ft cable length type of DPH-103-M5-R is "DPH-103-M5-R-C5"

#### Controllers

Appearance	Rated pressure range	Model No.	Comparative output
935 = -500	Compound pressure: -100.0 to +100.0 kPa	DPC-101	NPN open-collector transistor
* CN-66A-C2 (Connector attached cable 2 m 6.562 ft) is attached.	Positive pressure: 0 to +1.000 MPa Vacuum pressure: 0 to –101.0 kPa	DPC-101-P	PNP open-collector transistor

#### Type without connector attached cable

Type without connector attached cable **CN-66A-C2** is available. When ordering this type, suffix "-**J**" to the Model No. (e.g) Type without connector attached cable of **DPC-101-P** is "**DPC-101-P-J**".

#### Accessory

CN-14A-C2 (Connector attached cable 2 m 6.562 ft)



#### **OPTIONS**

Designation	Model No.		Description	
Sensor head connector (e-CON)	CN-EP2 (Note 1) 5 pcs. per set	Connector for c	connecting sensor head controller	
Connector	CN-66A-C2 (Note 2)	Length 2 m 6.562 ft	Controller power supply / I-O cable. 0.3 mm <sup>2</sup> 6-core oil-resistant cabtyre	
attached cable	CN-66A-C5	Length 5 m 16.404 ft		
Power supply connector	CN-66A 5 pcs. per set	Connector for controller power supply / I-O cable.		
Controller mounting bracket	MS-DP1-6	Allows sensors to be installed on the wall. Multiple sensors can also be mounted closely.		
Panel mounting bracket	MS-DP1-2	Allows installation to panels with thickness of 1 to 6 mm 0 to 0.236 in. Multiple sensors can also be mounted close		
Front protection cover MS-DP1-3		Protects the adjustment surfaces of controllers. (Can be attached when using the panel mounting bracket)		
Copy unit	SC-SU1	Copies controller setting details to other controllers.		

Notes: 1) One is attached to each sensor head according to standard.


2) The connector attached cable CN-66A-C2 is supplied with the controller according to standard.

#### **Power supply** connector


#### • CN-66A



#### **Controller mounting bracket**




#### Panel mounting bracket, Front protection cover



#### Specifications

#### **Copy unit** • SC-SU1



Designation	Copy unit			
Item Model No.	SC-SU1			
Applicable sensors	Digital pressure sensor: <b>DP-100</b> series, <b>DPC-100</b> series Digital fiber sensor: <b>FX-100</b> series			
Supply voltage (Note 1)	12 V DC [AC adapter (accessory): Input 100 to 240 V AC 50 / 60 Hz)]			
Repeatability of connecting and disconnecting (Note 2)	5,000 times approx.			
Ambient temperature	0 to +40 °C +32 to +104 °F (No dew condensation allowed), Storage: –10 to +60 °C +14 to +140 °F			
Ambient humidity	35 to 85 % RH, Storage: 35 to 85 % RH			
Material	Enclosure base: ABS, Top cover: ABS, Rubber foot: Natural rubber			
Weight	Net weight: 190 g approx. Gross weight: 350 g approx.			

Notes: 1) For destinations where the shape of the AC adapter plug differs from the shape for Japan, a separate conversion adapter is available.

2) Number of repeated operations may vary depending on the usage conditions.

#### **Recommended e-CON**

Model No.: 1473562-4 (Manufactured by Tyco Electronics) Note: Contact the manufacturer for details of the recommended products.

#### **Recommended power supply connector**

Contact: SPHD-001T-P0.5, Housing: PAP-06V-S (Manufactured by J.S.T. Mfg.Co., Ltd.) Note: Contact the manufacturer for details of the recommended products.

#### **Recommended crimping tool**

Model No.: YC-610R (Manufactured by J.S.T. Mfg. Co., Ltd.) Note: Contact the manufacturer for details of the recommended products.



#### Sensor head connector (e-CON)





Note: One is attached to each sensor head according to standard.

#### **Connector attached cable**

- CN-66A-C2
- CN-66A-C5



Note: The connector attached cable CN-66A-C2 is supplied with the controller according to standard.

#### **SPECIFICATIONS**

#### Sensor heads

$\swarrow$		Туре	Co	mpound press	ure	Positive	pressure	Vacuum pressure		
Туре		±100 kPa type 1 MPa ty		a type	pe –101 kPa type		e			
Item		Model No.(Note 3)	DPH-101(-R)	DPH-101-M3(-R)	DPH-101-M5(-R)	DPH-102	DPH-102-M5	DPH-103(-R)	DPH-103-M3(-R)	DPH-103-M5(-R
Туре	of pres	sure		Gauge pressure						
Rate	d pressu	ure range	-1	00.0 to +100.0 k	Pa	0 to +1.0	000 MPa		0 to –101.0 kPa	l
Pres	sure wit	hstandability		500 kPa		1.5	MPa		500 kPa	
Appl	icable flu	uid				Air, non-co	orrosive gas			
Supp	oly volta	ge			12 to 24	4 V DC ± 10 %	Ripple P-P 10 %	6 or less		
Curr	ent cons	sumption				15 mA	or less			
Analog voltage output		ge output	Zero point: wi wi Span: within Linearity: with	Output voltage: 1 to 5 V (over rated pressure range) Zero point: within 1 V ± 2.5 % F.S. (vacuum / positive pressure type) within 3 V ± 3 % F.S. (compound pressure type) Span: within 4 V ± 3.5 % F.S. Linearity: within ±0.5 % F.S. Output impedance: 1 kΩ approx.						,
a)	Protect	tion	IP40 (IEC)							
tanc	Ambier	nt temperature	0 to +50 °C +32 to +122 °F (No dew condensation allowed), Storage: -10 to +60 °C +14 to +140 °F						F	
Environmental resistance	Ambier	nt humidity	35 to 85 % RH, Storage: 35 to 85 % RH							
ntal	Voltage	e withstandability		1,000 V AC	000 V AC for one min. between all supply terminals connected together and enclosure					
nme	Insulat	ion resistance	50 M $\Omega$ , or more, with 500 V DC megger between all supply terminals connected together and enclosure						sure	
nvirc	Vibratio	on resistance	10 to 500 Hz fr	equency, amplitu	ude 3 mm <mark>0.118</mark> i	in or maximum a	acceleration 196	m/s <sup>2</sup> , in X, Y and	Z directions for	two hours each
ш	Shock	resistance	1,000 m/s <sup>2</sup> acceleration (100 G approx.) in X, Y and Z directions for three times each							
Tem	perature	characteristics	Over ambient temperature range 0 to +50 °C +32 to +122 °F: within ±2 % F.S. of detected pressure at +25 °C +77 °F							
Pres	sure por	rt	DPH-10□(-R): R <sup>1</sup> / <sub>8</sub> male thread + M5 female thread, DPH-10□-M3(-R): M3 male thread (for installing gasket) DPH-10□-M5(-R): M5 male thread (for installing gasket)							
Mate	erial		Front case: PBT, Rear case: PBT (glass fiber reinforced), Pressure port: Stainless steel (SUS303), O-ring: NBR Pressure element: Silicon diaphragm, PPS							
Conr	necting r	method	Connector							
Cabl	е		0.2 mm <sup>2</sup> 4-core oil resistant cabtyre cable (Models with "- <b>R</b> " affixed to the Model No. have flexible, oil-resistant cabtyre cable)							
Cabl	e extens	sion		Exten	sion up to total 1	0 m 32.808 ft is	possible with 0.	2 mm <sup>2</sup> , or more,	cable.	
\//o:-		Net weight	DPH-10	( <b>-R</b> ): Head 10 g	approx. / Cable	40 g approx., <b>Di</b>	PH-10□-M3/M5(-	-R): Head 6 g ap	prox. / Cable 40	g approx.
Weig	JIIC	Gross weight	<b>DPH-10</b> □( <b>-R</b> ): 80 g approx., <b>DPH-10</b> □ <b>-M3/M5</b> ( <b>-R</b> ): 70 g approx.							
Acce	essory		Connector (e-CON): 1 pc.							
	43.34/1	oro mogouromont o			a				.05.00 . 77.05	

Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +25 °C +77 °F. 2) The sensor head can be used independently. 3) Model No. having the suffix "-**R**" is flexible cable type.

#### SPECIFICATIONS

#### Controllers

~	Туре	NPN output type	PNP output type			
tem	Model No.	DPC-101	DPC-101-P			
Арр	licable sensor head	DPH-101□, DPH-	102□, DPH-103□			
Rated pressure range (Note 2)		Compound pressure: -100.0 to +100.0 kPa, Positive pressure: 0 to +1.000 MPa, Vacuum pressure: 0 to -101.0 kPa				
Set pressure range (Note 2)		Compound pressure: -199.9 to +199.9 kPa (-1.999 to +1.999 kgf/cm <sup>2</sup> , -19.98 to Positive pressure: -1.050 to +1.050 MPa (-10.71 to +10.71 kgf/cm <sup>2</sup> , -152.2 t Vacuum pressure: +101.3 to -101.3 kPa (+1.033 to -1.033 kgf/cm <sup>2</sup> , +14.70 to	to +152.2 psi, -10.50 to +10.50 bar)			
Sup	ply voltage	12 to 24 V DC ± 10 % F	Ripple P-P 10 % or less			
Pow	er consumption	Normal operation: 960 mW or less (Current cons ECO mode (STD): 720 mW or less (Current cons ECO mode (FULL): 600 mW or less (Current con Excluding the current consumption of sensor hea	sumption 30 mA or less at 24 V supply voltage) nsumption 25 mA or less at 24 V supply voltage)			
Sen	sor head supply voltage	Same as su	oply voltage			
	nparative outputs nparative output 1, 2)	<ul> <li>NPN open-collector transistor (2 outputs)</li> <li>Maximum sink current: 100 mA</li> <li>Applied voltage: 30 V DC or less (between comparative output and 0 V)</li> <li>Residual voltage: 1 V or less (at 100 mA sink current)</li> </ul>	PNP open-collector transistor (2 outputs) <ul> <li>Maximum source current: 100 mA</li> <li>Applied voltage: 30 V DC or less (between comparative output and +V)</li> <li>Residual voltage: 1 V or less (at 100 mA source current)</li> </ul>			
	Output operation	NO / NC, selectable	e by key operation			
	Output modes	EASY mode / Hysteresis mode	e / Window comparator mode			
	Hysteresis	Minimum 1 digit (variable) (howe	ver, 2 digits when using psi unit)			
	Repeatability	With vacuum / positive pressure type connected: within $\pm 0.2$ % F.S. ( $\pm 2$ digits) With compound pressure type connected: within $\pm 0.2$ % F.S. ( $\pm 4$ digits)				
	Response time	0.5 ms, 1 ms, 2.5 ms, 5 ms, 10 ms, 25 ms, 50 ms, 100 ms, 250 ms, 500 ms, 1,000 ms, 5,000 ms, selectable by key operation				
	Short-circuit protection	Incorporated				
Analog output		<analog output="" voltage=""> <ul> <li>Output current: 1 to 5 V DC</li> <li>Zero point: within 1 V ± 0.5 % F.S. (vacuum / positive pressure type) within 3 V ± 0.5 % F.S. (compound pressure type)</li> <li>Span: within 4 V ± 0.5 % F.S.</li> <li>Linearity: within ±0.1 % F.S.</li> <li>Output impedance: 1 kΩ approx.</li> </ul></analog>	<analog current="" output=""> <ul> <li>Output current: 4 to 20 mA</li> <li>Zero point: within 4 mA ± 1 % F.S. (vacuum / positive pressure type) within 12 mA ± 1.5 % F.S. (compound pressure type)</li> <li>Span: within 16 mA ± 1.5 % F.S.</li> <li>Linearity: within ±0.1 % F.S.</li> <li>Load resistance: 250 Ω (max.).</li> </ul></analog>			
	Sensor head input	Input voltage range: 1 to 5 V D	C (over rated pressure range)			
Inputs	External input (Auto-reference function/ Remote zero-adjustment) function	ON voltage: +0.4 V DC or less OFF voltage: +5 to +30 V DC, or open Input impedance: 10 kΩ approx. Input time: 1 ms or more	ON voltage: +5 V to +V DC OFF voltage: +0.6 V DC or less, or open Input impedance: 10 k $\Omega$ approx. Input time: 1 ms or more			
Disp	blay	4 digits + 4 digits 3-color LCD display (Display refresh rate	: 250 ms, 500 ms, 1,000 ms, selectable by key operation)			
	Displayable pressure range	Vacuum pressure: +5.1 to -101.3 kPa, Positive pressure: -0.05	50 to +1.020 MPa, Compound pressure: -101.3 to +105.0 kPa			
)pe	ration indicator	Orange LED (Comparative output 1 operation indicator, comparative outp	ut 2 operation indicator: Lights up when each comparative output is ON )			
	Protection	IP40 (IEC)				
2	Ambient temperature	-10 to +50 °C +14 to +122 °F (No dew condensation or icing allowed), Storage: -10 to +60 °C +14 to +140 °F				
	Ambient humidity	35 to 85 % RH, Storage: 35 to 85 % RH				
<u>מ</u>	Voltage withstandability	1,000 V AC for one min. between all supply terminals connected together and enclosure				
	Insulation resistance	50 M $\Omega$ , or more, with 500 V DC megger between all supply terminals connected together and enclosure				
	Vibration resistance	10 to 500 Hz frequency, amplitude 3 mm 0.118 in or maximum acceleration 196 m/s <sup>2</sup> , in X, Y and Z directions for two hours each (when panel mounting bracket is mounted : 10 to 150 Hz frequency, amplitude 0.75 mm 0.030 in or maximum acceleration 49 m/s <sup>2</sup> , in X, Y and Z directions for two hours each)				
Ī	Shock resistance	100 m/s <sup>2</sup> acceleration (10 G approx.) in X, Y and Z directions for three times each				
em	perature characteristics	Within ±0.5 % F.S. (ambient temperature range based on +20 °C +68 °F)				
/late	erial	Enclosure: PBT (glass fiber reinforced), LCD display: Acrylic, Mounti	ing threaded part: Brass (nickel plated), Switch part: Silicone rubber			
Con	necting method	Conn	ector			
Cab	le length	Total length up to 100 m 328.084 ft is p	possible with 0.3 mm <sup>2</sup> , or more, cable.			
Nei	ght	Net weight: 25 g approx. (excluding connector	attached cable), Gross weight: 140 g approx.			
Acc	essories	CN-66A-C2 (Connector attached cable	2 m 6.562 ft), Pressure unit label: 1 set			
		I sounditions have not been encoified precisely, the conditions used i	were an ambient temperature of ±20 °C ±69 °E			


Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +20 °C +68 °F. 2) It changes automatically according to the connected pressure sensor head. 3) The values specified above are applied only to the controller.



#### I/O CIRCUIT AND WIRING DIAGRAMS

#### **DPC-101**


#### I/O circuit diagram




Notes: 1) Select and use the auto-reference function and remote zero-adjustment function. 2) Set the output load resistance during analog current output to 250  $\Omega$  (max.) 3) Note that a voltage of +5 V or higher is generated during analog current output.

Symbols D1, D2	: Reverse supply polarity protection diode
ZD1 to ZD3	: Surge absorption zener diode
Tr1, Tr2	: NPN output transistor

\*1



#### **Terminal arrangement diagram**



#### Connector for power supply / I-O cable (CN1)

(1) **+V** 


- 2 Analog voltage / current output
- 3 0 V
- ④ Comparative output 1
- (5) Comparative output 2
- External input (auto-reference function/ remote zero-adjustment function)

#### Connector for sensor head (CN2)

- (1) Sensor head supply voltage
- Analog voltage input
- 3 0 V
- (4) Model discrimination signal

#### For independent use of sensor head

NPN output type



independently, insulate the white lead wire (terminal No.4) and keep it open.
2) When the sensor head is used independently, devices connected to the analog output must have an input impedance set at 50 kΩ or more.


Symbols ... D: Reverse supply polarity protection diode ZD: Surge absorption zener diode

#### I/O CIRCUIT AND WIRING DIAGRAMS

#### DPC-101-P

PNP output type







Notes: 1) Select and use the auto-reference function and remote zero-adjustment function. 2) Set the output load resistance during analog current output to 250  $\Omega$  (max.) 3) Note that a voltage of +5 V or higher is generated during analog current output.

Symbols ... D1 to D3 : Reverse supply polarity protection diode ZD1 to ZD3: Surge absorption zener diode Tr1, Tr2 : PNP output transistor

\*1



#### Terminal arrangement diagram




- Connector for power supply / I-O cable (CN1)
- (1) **+V**
- 2 Analog voltage / current output
- 3 0 V
- ④ Comparative output 1
- 6 Comparative output 16 Comparative output 2
- External input (auto-reference function/ remote zero-adjustment function)

#### Connector for sensor head (CN2)

10/2008

- (1) Sensor head supply voltage
- ② Analog voltage input
- 3 0 V
- (4) Model discrimination signal





Notes: 1) In case the sensor head is used independently, insulate the white lead wire (terminal No.4) and keep it open.
2) When the sensor head is used independently, devices connected to

the analog output must have an input impedance set at 50 k $\Omega$  or more.

Symbols ... D: Reverse supply polarity protection diode ZD: Surge absorption zener diode

#### PRECAUTIONS FOR PROPER USE

- Never use this product as a sensing device for personnel protection.
- In case of using sensing devices for personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection

applicable in each region or country.

• The **DPH-100** series is designed for use with air and non-corrosive gas. It cannot be used with liquid or corrosive and inflammable gases.

#### **Part description**





#### Wiring

- Make sure that the power supply is off while wiring.
- Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this sensor, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
- · Incorrect wiring will cause problems with operation.

#### Connection

• Do not apply stress directly to the connection cable leader or to the connector.






<Connector of connector attached cable> Housing: PAP-06V-S [Manufactured by J.S.T Mfg. Co. Ltd.]


Connector of sensor head cable> e-CON: 1473562-4 [Manufactured by Tyco Electronics]

#### Mounting

 When tightening the controller to the controller mounting bracket MS-DP1-6 (optional), use a tightening torque of 0.5 N•m or less.



• The **MS-DP1-2** panel mounting bracket (optional) and the **MS-DP1-3** front protection cover (optional) are also available.



#### Piping

• Use a hexagonal wrench to install sensor head. For the tightening torque, refer to the following diagram. If excessive tightening torque is applied, the pressure port of the sensor head or the M5 male screw of the commercial coupling will get damaged. In case of R% male thread type, wrap sealing tape around the coupler when connecting to prevent leakage.



Pressure port	Hexagonal wrench (bolt width)	Tightening torque
R <sup>1</sup> ∕₃ male thread	5 mm 0.197 in	9.8 N·m or less
M3 male thread	3 mm 0.118 in	0.8 N·m or less
M5 male thread	3 IIIII 0. I 10 III	1.5 N·m or less

#### Others

- This product has been developed / produced for industrial use only.
- · Use within the rated pressure range.
- Do not apply pressure exceeding the pressure withstandability value. The diaphragm will get damaged and correct operation shall not be maintained.
- Do not use during the initial transient time (controller: 0.5 sec. approx, sensor head: 50 ms approx.) after the power supply is switched on.
- · Avoid dust, dirt, and steam.
- Take care that the sensor does not come in direct contact with water, oil, grease, or organic solvents, such as, thinner, etc.
- Do not insert wires, etc., into the pressure port. The diaphragm will get damaged and correct operation shall not be maintained.
- 10/2008 Do not operate the keys with pointed or sharp objects.

#### PRECAUTIONS FOR PROPER USE

#### **RUN mode**

• This is the normal operating mode.

Setting item	Description
Threshold value setting	The threshold values for ON / OFF operation can be changed directly by pressing the increment key (UP) and the decrement key (DOWN).
Zero-adjustment function	This forces the pressure value display to be reset to zero when the pressure port is open on the atmospheric pressure side.
Key lock function	Stops key operations from being accepted.
Peak hold / bottom hold function	Displays the peak value and bottom value for fluctuating pressure. The peak value appears in the main display, and the bottom value appears in the sub display.

#### **MENU SETTING mode**

- If the mode selection key is pressed and held for 2 sec. in RUN mode, the mode will switch to MENU SETTING mode.
- If the mode selection key is pressed while a setting is being made, the mode will switch to RUN mode. In this case, the settings that have been changed will be entered.

Setting item	Description
Comparative output 1 output mode setting	Sets the output mode for comparative output 1.
Comparative output 2 output mode setting	Sets the output mode for comparative output 2.
Analog voltage / current output selection	Selects analog voltage output or analog current output.
External input selection	Selects auto-reference function, or remote zero- adjustment function.
NO / NC selection	Normally open (NO) or normally closed (NC) can be selected.
Response time setting	Sets the response time. The response time can be selected from 0.5 ms, 1 ms, 2.5 ms, 5 ms, 10 ms, 25 ms, 50 ms, 100 ms, 250 ms, 500 ms, 1,000 ms and 5,000 ms.
Display color switching for main display	Allows the color for the main display to be changed. The colors can be set to "red / green" or "green / red" to correspond to ON / OFF output, or it can be fixed at "red" or "green" all the time.
Unit switching	Pressure unit can be changed.

#### PRO mode

- If the mode selection key is pressed and held for 5 sec. in RUN mode, the mode will switch to PRO mode.
- If the mode selection key is pressed while a setting is being made, the mode will switch to RUN mode. In this case, the settings that have been changed will be entered.

Setting item	Description
Sub display switching	Changes the information in the sub display during RUN mode operation to the current pressure unit, numder and desired alphanumeric display.
Display refresh rate switching	Changes the display refresh rate for the pressure value displayed in the main display.
Hysteresis fix value switching	Sets the hysteresis for EASY mode and window comparator mode. (8 steps)
Linked display color switching	Allows the display color for the main display to be switched in line with the output operation for comparative output 1 or comparative output 2.
External input relation selection	The setting contents set at the external input selection in MENU SETTING mode can be shifted to correspond to either comparative output 1, 2 or 1 / 2.
ECO mode setting	Allows power consumption to be reduced by dimming the display or turning it off.
Setting check code	Allows the setting details to be checked via codes. (Refer to below)
Setting copy mode	Allows the setting details for the master controller to be copied to slave controllers.
Reset setting	Resets the settings to the factory settings.

#### Table of codes

е	1st digit		2nd digit		3rd digit		4th digit	
Code	Comparative output 1 output mode	NO / NC selection	Comparative output 2 output mode	NO / NC selection	Analog output	Threshold display	External input	
0	EASY	NO	OFF	—		Threshold value 1	OFF	—
1	EAST	NC	EASY	NO	Analog	Threshold value 2	Auto-	Comparative output 1
2		NO	EAST	NC	voltage	Threshold value 3		Comparative output 2
3	Hysteresis	NC	Hysteresis	NO	output	Threshold value 4	reference	Comparative output 1/2
Ч	Window	NO		NC		Threshold value 1		Comparative output 1
5	comparator	NC	Window	NO	Analog	Threshold value 2	Remote zero-	Comparative output 2
6	_	—	comparator	NC	current	Threshold value 3	adjustment	Comparative output 1/2
7	_	_	_	_		Threshold value 4	_	_
			<u> </u>					




			$ \longrightarrow $	$\rightarrow$		
٥	5th digit		6th digit	7th digit	8th digit	
Code	Displayed color of the main display	Displayed color relation	Response time	Unit selection (Note)	Display refresh rate	Eco mode
0	Red when ON	Comparative output 1	0.5 ms	MPa	250 ms	OFF
1		Comparative output 2	1 ms	kPa		STD
2	Green when ON	Comparative output 1	2.5 ms	kgf/cm <sup>2</sup>		FULL
З		Comparative output 2	5 ms	bar		OFF
Ч	Always red	Comparative output 1	10 ms	psi	500 ms	STD
5		Comparative output 2	25 ms	mmHg		FULL
Б	Always green	Comparative output 1	50 ms	inHg		OFF
٦		Comparative output 2	100 ms	_	1,000 ms	STD
8	_	_	250 ms	_		FULL
9	_	_	500 ms	_	_	_
Я	—	_	1,000 ms	_	_	_
₿	_	_	5,000 ms	_	_	_


10/2008 **SUNX** 

#### **DIMENSIONS (Unit: mm in)**

The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.com





DPC-101(-P)



18


0 709





Controller mounting bracket (Optional)

MS-DP1-6




20.2


7.3 ÷

3.8 0.150

30 0.795 .181

**Assembly dimensions** 





Material : Cold rolled carbon steel (SPCC) (Uni-chrome plated) Two M3 (length 6 mm 0.236 in) screws with washers are attached.

#### DIMENSIONS (Unit: mm in)

The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.com


Panel mounting bracket (Optional), Front protection cover (Optional)


#### MS-DP1-2 MS-DP1-3

#### **Assembly dimensions**

#### Mounting drawing with DPC-101

#### Vertical mounting





View A

31\_0\_.4


.220

#### Panel cut-out dimensions

When 1 unit is installed

31<sub>-0.4</sub>  $1.220_{-0.106}^{0}$  series 131 1.220 × n + 3.5 0.138 × (n-1)

When "n" units are installed horizontally in




#### CN-66A-C2 CN-66A-C5

31\_0.4


Note: The panel thickness should be 1 to 6 mm 0.039 to 0.236 in.

#### When "n" units are installed vertically in series



View A

#### Connector attached cable (Optional, CN-66A-C2 is attached to the controller)




Length L					
Model No.	Length L				
CN-66A-C2	2,000 78.740				
CN-66A-C5	5,000 196.850				




#### DIMENSIONS (Unit: mm in)

The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.com



#### **Guide to Integrated Digital Pressure Sensors**



The dual display allows the current value and the threshold value to be displayed simultaneously to improve ease of operation and viewing. These sensors represent the newest standard in digital pressure sensors.

- •Dual display lets you set the threshold value directly The current value and the threshold value can be checked simultaneously. You can confirm and change the threshold value directly without the need to switch displays.
- •3-color LCD (Red / Green / Orange)

The color of the digital displays changes in line with the ON / OFF status of output, as well as during sensor setting. This lets you see the sensor status at a glance and reduces operating errors.

•Equipped with a useful setting copy function for when using multiple sensors

Data transmission can be used to copy settings. This feature is ideal for reducing man-hours and preventing setting errors from occurring.



All information is subject to change without prior notice.



http://www.sunx.com

**SUNX Limited** 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan Phone: +81-568-33-7211 FAX: +81-568-33-72631

Overseas Sales Division Phone: +81-568-33-7861 FAX: +81-568-33-8591